
MAGNETIC Signature MAGNETC SICHUTCIRE Sensor Reading POWER (BATTERY) · Carteidge CONTROLLER SPEAKER

Figure 2







Figure 4a



Tigure 4b





Figure 4C



2168	SENSOR					STATE					
PAGE	, 1	Н	H	Н	H	H	H	H	H	H	H
IPAGE	<u> </u>		H	H	Н	H	H	Н	H	H	H
2PAGE	L	L			H	H	H	H	Н	H	H
3PAGE	4	L	L	H			H	H	H	H	H
4PAGE	L	L	L	L	H	H				H	H
5PAGE	L	L	L	L	L	H	H	H	H	┼	
SPAGE	L	L	L	L	L	L	H	H	H	H	H
7PAGE	L	L	L	L	L	L	L	H	H	H	H
<b></b>		1	<u> </u>	L	L	L	L	L	Н	H	H
SPAGE	L	-	<del></del>	<del></del>		L	L	L	L	H	H
9PAGE	L	<u> </u>	L	L	1-	+-	+-	+-	+-	+:	1:
:	:	:	:	:							
:	:	<u> </u> :	<u>  :</u>	<u> </u>	<del>  -</del>	+	<del>                                     </del>	+:	+:	+	
n-IPAG	EL	L	L	L	L	L	L	L	I	.   [	

L-Low H-High

Figure 6